

Sun Of Bubba

Light Weight Cross Country Racing Hub

INSTALLATION AND MAINTENANCE INSTRUCTIONS

WHEEL BUILDING

The S.O.B. is designed to use both 14 and 15 gauge spokes, either straight or butted in three cross, two cross, one cross, or radial. Three and two cross are preferred but any of the above will work without voiding the factory warranty.

HUB DIMENSIONS

Center to Flange	34 mm
Flange Diameter	38 mm

MAINTENANCE

The S.O.B. hub is supplied with high quality double sealed bearings; it is best to leave these alone. The seals and factory lubrication have proven to be very effective against dirt, dust, grime, and water spray. However, when cleaning your bike, do not spray solvents or water near the bearing seals. Also submersion of the bearing during water crossing should be avoided. Splashing through a shallow crossing is OK, but going through axle deep water is a surefire way to contaminate the bearings and reduce their service life

The S.O.B. bearings are replaceable. However, under normal use they will last for years. At some point you may wish to have the bearings replaced. This should be performed by a Sun Ringle dealer.

SUN RINGLE LIMITED WARRANTY: Sun Ringle racing components warrants to the original retail purchaser that all of its products are of the finest quality and are free from manufacturer defects for a period of one year from the date of original retail purchase (so like many items it is a good idea to keep your receipt just in case of a warranty claim). It is at the sole discretion of Sun Ringle racing components to repair or replace any one of its products during the above warranty period. ALL warranties are VOID if product is subject to abuse, crash, damage, neglect or lack of maintenance, improper installation, improper repair, alterations or use unintended by the manufacturer. This warranty is in lieu of all other agreements and warranties, general or special, express or implied and no representative or person is authorized to assume any liability on behalf of Sun Ringle' racing components in connection with the sale or use of our products.

IF YOU HAVE A WARRANTY CLAIM: Contact your dealer, who can handle your claim or notify Sun Ringle before returning any merchandise to our factory. Please call to explain your product situation and request a return authorization number. Upon acknowledgment by Sun Ringle' of any possible warranty, pack and ship the product to Sun Ringle freight prepaid, with the return authorization number written clearly on the outside of the box, and please include original proof of purchase. Sun Ringle will not accept ANY merchandise returned to us without an R.A. number or returned to us freight collect.

Sun-Ringle Racing Components
800 W. 4th St., North Manchester, IN 46962
Cust. Service (219) 982-6410 Sales (219) 267-3281